













PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

ANNIKA II 28






LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



$AB=CD$




ANNIKA II 28



MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.




ANNIKA II 28



THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **5%**


ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.

ANNIKA II 28





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

ANNIKA II 28




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

ANNIKA II 28



DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

ANNIKA II 28





INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

ANNIKA II 28

6x140 × 12



Ø 5 mm



INSTALL THE ROOF PURLINS AND ATTACH THEM WITH SCREWS.

ANNIKA II 28



6x140 × 3
Ø 5 mm



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH 6 SCREWS, 3 INTO **EACH** NEXT, SAW THE LAST **BOARD** TO MAKE IT FIT.

ANNIKA II 28



4x50  x 135



FOR THE FASCIA TRIMS INSERT
SCREWS AFTER EVERY 0,5 METERS.

ANNIKA II 28

4x40
× 44







EAVES EDGES GO ON TOP OF THE ROOFING*.

*(NOT INCLUDED)

ANNIKA II 28


4x40
×24

Ø 3 mm





14 SCREWS INTO THE FIRST FLOORBOARD,
7 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.

4x50
× 160




ANNIKA II 28



SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.


1,4×40
× 35




DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x60 × 12


Ø 8 mm



ANNIKA II 28






WINDBOARD





IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90° .

ANNIKA II 28



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

ANNIKA II 28



WHEN THE HOUSE IS ASSEMBLED, YOU SHOULD COVER THE TIMBER WITH WOOD PROTECTIVE SEAL, PAINT OR STAIN AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE WOOD.

ANNIKA II 28

