




PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

ARBOGA I 40



4x40 × 45

4x50 × 470



5x70 × 50

6x140 × 50



M8x70 × 15

1,4X40 × 30

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.







ARBOGA I 40







MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%



ATTACH FOUNDATION BEAMS WITH SCREWS.

ARBOGA I 40


- 5×70  $\times 2$
- 6×140  $\times 8$
- $\varnothing 4 \text{ mm}$ 
- $\varnothing 5 \text{ mm}$ 







LAY OUT THE BOTTOM LOGS SO,
THAT DOOR **OPENING** WILL BE
1441 MM WIDE





ARBOGA I 40



ATTACH LOGS TO THE FOUNDATION.





5×70  $\times 4$ 6×140  $\times 10$
 $\varnothing 4 \text{ mm}$  $\varnothing 5 \text{ mm}$ 



ARBOGA I 40

THE WALL LOGS WILL HANG OVER THE FOUNDATION BEAMS BY APPROXIMATELY 5MM. THIS OVERHANG IS DESIGNED AS A RAIN DRIP. 6%


ATTACH THE NEXT ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.



ARBOGA I 40



AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

ARBOGA I 40




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

ARBOGA I 40



DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

ARBOGA I 40




SLIDE THE WINDOW IN,
ATTACH THE HANDLE.

ARBOGA I 40





ARBOGA I 40



INSTALL **CEILING** TRIANGLE
AND **ATTACH** WITH SCREWS
INTO THE WALLS.

4x50 × 6 5x70 × 5

ARBOGA I 40



CEILING
DETAIL
40x120

CEILING
TRIANGLE



LEAVE 4CM GAP BETWEEN
DOOR AND **CEILING** DETAIL,
ATTACH IT INTO **WALLS** AND INTO
CEILING TRIANGLE USING SCREWS **47%**

ATTACH TOP LOGS INTO WALL LOGS WITH SCREWS.

ARBOGA I 40



6x140 × 24

Ø 5 mm



CONNECT THE ROOF PURLINS (RFR) WITH RD BEFORE INSTALLING THEM ON TOP OF THE CORNERS.

ARBOGA I 40




INSTALL THE **ROOF** PURLINS AND ATTACH THEM WITH SCREWS.

6x140 × 4
Ø 5 mm



ARBOGA I 40





INSTALL THE **ROOF** PURLINS (RFB) AND ATTACH THEM WITH SCREWS.

ARBOGA I 40

5x70 × 8 6x140 × 8

Ø 4 mm

Ø 5 mm





PLACE THE FIRST ROOFBOARD FLUSH WITH THE END OF THE PURLINS AND ATTACH WITH SCREWS

4x50 × 256



ARBOGA I 40






RB16

INSTALL THE ROOF TOP AND ATTACH IT WITH SCREWS. ATTACH FASCIA TRIMS INTO ROOFPURLINS.




ARBOGA I 40

4x40
× 40




SCREW THE **FLOORBOARDS** INTO FOUNDATION, SAW THE LAST **BOARD** TO MAKE IT FIT.

ARBOGA I 40




SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.

1,4X40
× 30





ARBOGA I 40




DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x70 × 15

Ø 8 mm





ARBOGA I 40



WINDBOARD


IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90° .

ARBOGA I 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS OR THERE IS A GAP **BETWEEN** THEM, **ADJUST** 3 SCREWS ON DOOR HINGES.

ARBOGA I 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

ARBOGA I 40

