



PREPARE THE GROUND, UNWRAP THE PACKAGE,  
LAY OUT THE COMPONENTS, FIND THE TOOLS.


BENTE I 28




LAY OUT THE FOUNDATION BEAMS  
AND SQUARE IT BY MEASURING  
FROM CORNER TO CORNER.



$AB=CD$






BENTE I 28



MAKE SURE THAT THE FOUNDATION  
IS INSTALLED ON A LEVEL SURFACE.  
CHECKING ALL DIRECTIONS,  
INCLUDING CORNER TO CORNER. 3%





LAY OUT THE **BOTTOM** LOGS,  
**ATTACH** TO THE FOUNDATION.

BENTE I 28




THE WALL **LOGS** WILL HANG OVER  
THE FOUNDATION **BEAMS** BY  
**APPROXIMATELY** 5MM. THIS OVERHANG  
IS DESIGNED AS A RAIN DRIP. **5%**

ATTACH THE FIRST ROW OF  
WALL LOGS INTO THE BOTTOM  
LOGS WITH SCREWS.





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

BENTE I 28




SLIDE THE DOOR IN,  
ATTACH THE HANDLE.

BENTE I 28



DON`T FORGET TO  
**TIGHTEN** THE LOGS AFTER  
EVERY 3-4 ROWS.

BENTE I 28







INSTALL THE GABLES WITH LONG SCREWS  
TO THE WALL LOGS ON THE FRONT AND  
REAR WALLS.

6x140  
× 4

Ø 5 mm






BENTE I 28



INSTALL THE **ROOF** PURLINS AND  
**ATTACH** THEM WITH SCREWS.


6x140  
× 6  
Ø 5 mm





BENTE I 28

PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE  
END OF THE **PURLINS** AND ATTACH  
WITH 6 SCREWS, 3 INTO **EACH** NEXT,  
SAW THE LAST **BOARD** TO MAKE IT FIT.

4x50  
× 132





BENTE I 28



INSERT FOR THE FASCIA TRIMS  
SCREWS AFTER EVERY 0,5 METERS.

BENTE I 28

4x40  
× 20




EAVES EDGES GO ON TOP  
OF THE ROOFING\*.

\*(NOT INCLUDED)

4x40  
× 32

Ø 3 mm






BENTE I 28

ATTACH ROMBS WITH SCREWS.


BENTE I 28

4×40  
× 4  
Ø 3 mm





10 SCREWS INTO THE FIRST FLOORBOARD,  
5 INTO EACH NEXT, SAW THE  
LAST BOARD TO MAKE IT FIT.

4x50  
× 135






BENTE I 28





SAW THE **BASEBOARDS**  
AND ATTACH WITH NAILS  
AT **EVERY 0,5** METERS.

1,4×40  
× 25








DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x60 × 12

Ø 8 mm





BENTE I 28



WINDBOARD


IF DOOR IS TILTED,  
PUSH THE DOOR FRAME SO  
THAT ALL CORNERS ARE  $90^\circ$ .

BENTE I 28



IF **DOORS** ARE IN DIFFERENT HEIGHTS  
OR THERE IS A GAP **BETWEEN** THEM,  
**ADJUST** 3 SCREWS ON DOOR HINGES.

BENTE I 28



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

BENTE I 28

