







PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

BENTE III 28



4x40 × 55

4x50 × 370


5x70 × 10

6x140 × 30



M8x60 × 12

1,4x40 × 30

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.






BENTE III 28



MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%



LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.

BENTE III 28




THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **5%**

ATTACH THE FIRST ROW OF WALL LOGS INTO THE BOTTOM LOGS WITH SCREWS.




BENTE III 28





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

BENTE III 28




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

BENTE III 28



DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.




BENTE III 28



INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

BENTE III 28



6x140 × 4
Ø 5 mm



INSTALL THE ROOF PURLINS AND ATTACH THEM WITH SCREWS.

BENTE III 28



6x140 × 6
Ø 5 mm



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH 6 SCREWS, 3 INTO **EACH** NEXT, SAW THE LAST **BOARD** TO MAKE IT FIT.

4x50  × 186



BENTE III 28



INSERT FOR THE FASCIA TRIMS
SCREWS AFTER EVERY 0,5 METERS.

BENTE III 28

4x40
× 28




EAVES EDGES GO ON TOP OF THE ROOFING*.

*(NOT INCLUDED)

BENTE III 28

4x40 × 28


Ø 3 mm



ATTACH ROMBS WITH SCREWS.


BENTE III 28

4x40
× 4
Ø 3 mm





16 SCREWS INTO THE FIRST FLOORBOARD,
8 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.

4x50  × 162






BENTE III 28





SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.

1,4×40
× 30


BENTE III 28



DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.




BENTE III 28



WINDBOARD


IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90° .

BENTE III 28



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

BENTE III 28



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

BENTE III 28

