







PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.



GARAGE



LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



GARAGE








MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 2%

ATTACH FOUNDATION BEAMS WITH SCREWS.





GARAGE



6x140
× 4
Ø 5 mm



LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.




GARAGE

5×70  $\times 4$ 6×140  $\times 14$
 $\varnothing 4 \text{ mm}$  $\varnothing 5 \text{ mm}$ 




THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **4%**

ATTACH THE FIRST ROW OF WALL LOGS INTO THE BOTTOM LOGS WITH SCREWS.





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

GARAGE






SLIDE THE DOORS IN,
ATTACH THE HANDLES.

GARAGE



ASSEMBLY VERSION 2:
REMOVE BOTTOM PART OF
THE DOORFRAME TO LOWER
THE THRESHOLD.


SPARE PARTS FOR DOOR



REPLACE THE 95MM TOP LATH OF THE
DOOR WITH 120MM LATH 4%

SLIDE THE **WINDOWS** IN,
ATTACH THE **HANDLES**.

GARAGE



INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

6x140 × 6

Ø 5 mm

A TL-1

A LG-2

1 LG-6

B TL-1



B LG-4

2 LG-5

17 LOGS IN PLACE



GABLE

GARAGE




INSTALL THE **ROOF** PURLINS AND **ATTACH** THEM WITH SCREWS.

6x140 × 9
Ø 5 mm





GARAGE



GARAGE

PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE **END** OF THE PURLINS AND ATTACH WITH 6 SCREWS, 3 **INTO** EACH NEXT. SAW THE LAST **BOARD** TO MAKE IT FIT.



4x50  × 336



FOR THE FASCIA TRIMS
INSERT **SCREWS** AFTER EVERY
0,5 METERS.

GARAGE

4x40
× 52



EAVES EDGES GO ON TOP OF THE ROOFING*.



*(NOT INCLUDED)

4x40 × 32

Ø 3 mm

RF EE

GARAGE





ATTACH ROMBS WITH SCREWS.

GARAGE

4x40
× 4



Ø 3 mm

ROMB




WINDBOARD CONNECTS BOTTOM LOG WITH FIRTS LOG OF THE GABLE.


SAW THE WINDBOARD INTO THE RIGHT LENGTH. FOR THE TOP BOLT, DRILL 8MM HOLE THROUGH THE WINDBOARD.



Ø 8 mm



GARAGE





WINDBOARD

DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLTS. 97%


IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90° .

GARAGE



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

GARAGE



WHEN THE HOUSE IS ASSEMBLED, YOU SHOULD COVER THE TIMBER WITH WOOD PROTECTIVE SEAL, PAINT OR STAIN AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE WOOD.

GARAGE

