







PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

BODEN II 40



4x40 × 120

4x50 × 700

5x70 × 45



6x140 × 80

M8x70 × 20



6x160 × 6

1,4x40 × 50

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



BODEN II 40




MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 1%

ATTACH FOUNDATION BEAMS WITH SCREWS.





BODEN II 40



6x140 × 12
Ø 5 mm



LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.




BODEN II 40

5×70  $\times 4$ 6×140  $\times 10$
 $\varnothing 4 \text{ mm}$  $\varnothing 5 \text{ mm}$ 




THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **3%**

ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

BODEN II 40




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

BODEN II 40




DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.


BODEN II 40



SLIDE THE WINDOW IN,
ATTACH THE HANDLE.

BODEN II 40







INSTALL THE **CEILING** BEAMS AND **ATTACH** THEM WITH SCREWS.

BODEN II 40

6x140 × 4
Ø 5 mm




2 LG-4

4 LG-11

3 LG-1

1 LG-11




CB



INSTALL THE BEAM AND ATTACH WITH SCREWS.

BODEN II 40

5x70 × 11
Ø 4 mm





DRILL **8 MM** HOLE IN THE MIDDLE OF THE POSTS BOTTOM. ATTACH **POST FOOT** WITH SCREWS.

BODEN II 40

4x40 × **8**

Ø 3 mm





Ø 8 mm



SCREW IN THE SECOND PART OF THE POSTFOOT. **36%**



ATTACH THE **POSTS** TO THE WALL WITH SCREWS. MAKE SURE THAT THEY **ARE** STRAIGHT.

BODEN II 40



SCREW OUT THE SECOND PART OF THE POST FOOT SO THAT IT TIGHTLY TOUCHES THE GROUND.



BODEN II 40



DEPENDING ON THE SURFACE USE SCREWS OR ANCHOR BOLTS TO ATTACH THE POST FOOT TO THE GROUND. 38%

INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.



6x140 × 4
Ø 5 mm



BODEN II 40

INSTALL THE **ROOF** PURLINS AND **ATTACH** THEM WITH SCREWS.

6x160 × 6
Ø 5 mm






BODEN II 40

PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH 6 SCREWS, 3 INTO **EACH** NEXT, SAW THE LAST **BOARD** TO MAKE IT FIT.

4x50  × 276


BODEN II 40



FOR THE FASCIA TRIMS INSERT
SCREWS AFTER EVERY 0,5 METERS.

BODEN II 40

4x40
× 44





EAVES EDGES GO ON TOP OF THE ROOFING*.


*(NOT INCLUDED)

4x40 × 32

Ø 3 mm




BODEN II 40



ATTACH ROMBS WITH SCREWS.



BODEN II 40

4×40
 $\times 4$
 $\varnothing 3 \text{ mm}$





12 SCREWS INTO THE FIRST FLOORBOARD,
6 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.

4x50
× 204




10 SCREWS INTO THE FIRST FLOORBOARD,
5 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.

4x50
× 130





BODEN II 40




SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.

1,4×40
× 50





BODEN II 40




DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x70 × 20

Ø 8 mm



BODEN II 40






WINDBOARD

ASSEMBLE THE STAIRCASE.

BODEN II 40



6x140 ×36
Ø 5 mm



90%

CUT THE **BOARDS** TO
INSTALL THE **STAIRCASE**
AGAINST THE WALL.



4x40
× 8



SET THE **STAIRCASE** AT THE RIGHT SPOT,
ATTACH THE FIRST **HALF** OF THE LADDER
FITTINGS TO THE WALL **WITH** SCREWS. 93%

CONNECT THE OTHER HALF OF THE LADDER FITTINGS AND ATTACH THEM WITH SCREWS TO THE STAIRCASE.

4x40
× 8




BODEN II 40


CUT THE **BOARDS** TO INSTALL THE FENCE DETAILS AGAINST THE WALL. **ATTACH** THEM WITH SCREWS.

5x70 × 10

Ø 4 mm






BODEN II 40



ATTACH NEXT THE
FENCE DETAILS.







BODEN II 40

4x50 × 16
Ø 3 mm





SAW THE **FENCE** DETAILS INTO THE RIGHT SIZE AND SHAPE, **ATTACH** WITH SCREWS.

BODEN II 40




IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90° .

BODEN II 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS OR THERE IS A GAP **BETWEEN** THEM, **ADJUST** 3 SCREWS ON DOOR HINGES.

BODEN II 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

BODEN II 40

