












PREPARE THE GROUND, UNWRAP THE PACKAGE,  
LAY OUT THE COMPONENTS, FIND THE TOOLS.



# BRANTEVIK I 40



LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.





BRANTEVIK I 40




MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

LAY OUT THE **BOTTOM** LOGS,  
**ATTACH** TO THE FOUNDATION.




# BRANTEVIK I 40





THE WALL **LOGS** WILL HANG OVER  
THE FOUNDATION **BEAMS** BY  
**APPROXIMATELY** 5MM. THIS OVERHANG  
IS DESIGNED AS A RAIN DRIP. **5%**

ATTACH THE FIRST ROW OF  
**WALL LOGS** INTO THE BOTTOM  
LOGS WITH **SCREWS**.




# BRANTEVIK I 40




AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

BRANTEVIK I 40




SLIDE THE DOOR IN,  
ATTACH THE HANDLE.

# BRANTEVIK I 40




DON`T FORGET TO  
**TIGHTEN** THE LOGS AFTER  
EVERY 3-4 ROWS.

BRANTEVIK I 40



SLIDE THE WINDOW IN,  
ATTACH THE HANDLE.

BRANTEVIK I 40







INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

BRANTEVIK I 40

6x140 × 4  
Ø 5 mm





14 LOGS IN PLACE

INSTALL THE ROOF PURLINS AND ATTACH THEM WITH SCREWS.

BRANTEVIK I 40


6x140 × 6  
Ø 5 mm



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH 6 SCREWS, 3 INTO **EACH** NEXT, SAW THE LAST **BOARD** TO MAKE IT FIT.



BRANTEVIK I 40

4x50  
× 258



FOR THE FASCIA TRIMS INSERT  
SCREWS AFTER EVERY 0,5 METERS.

4x40  
× 40




EAVES EDGES GO ON TOP OF THE ROOFING\*.

\*(NOT INCLUDED)

# BRANTEVIK I 40


4x40 × 32

Ø 3 mm



RF




EE



ATTACH ROMBS WITH SCREWS.



BRANTEVIK I 40

4x40 × 4  
Ø 3 mm



14 SCREWS INTO THE FIRST FLOORBOARD,  
7 INTO EACH NEXT, SAW THE  
LAST BOARD TO MAKE IT FIT.



4x50  
× 204



SAW THE **BASEBOARDS**  
AND ATTACH WITH NAILS  
AT **EVERY 0,5** METERS.






1,4×40  
× 30

BRANTEVIK I 40





WINDBOARD CONNECTS BOTTOM LOG WITH THE TOP LOG. SAW THE WINDBOARD INTO THE RIGHT LENGTH. FOR THE TOP BOLT, DRILL 8MM HOLE THROUGH THE WINDBOARD.





WINDBOARD

DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLTS. 97%


IF DOOR IS TILTED,  
PUSH THE DOOR FRAME SO  
THAT ALL CORNERS ARE 90°.

# BRANTEVIK I 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS OR THERE IS A GAP **BETWEEN** THEM, **ADJUST** 3 SCREWS ON DOOR HINGES.

# BRANTEVIK I 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

# BRANTEVIK I 40

