



PREPARE THE GROUND, UNWRAP THE PACKAGE,  
LAY OUT THE COMPONENTS, FIND THE TOOLS.

# BRANTEVIK II 40



4x40 × 75

4x50 × 540




5x70 × 10

6x140 × 30

M8x70 × 12

1,4x40 × 30





LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.





MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

LAY OUT THE **BOTTOM** LOGS,  
**ATTACH** TO THE FOUNDATION.

# BRANTEVIK II 40




$5 \times 70$    $\times 4$      $6 \times 140$    $\times 14$   
 $\varnothing 4 \text{ mm}$       $\varnothing 5 \text{ mm}$  



THE WALL **LOGS** WILL HANG OVER  
THE FOUNDATION **BEAMS** BY  
**APPROXIMATELY** 5MM. THIS OVERHANG  
IS DESIGNED AS A RAIN DRIP. **5%**


ATTACH THE FIRST ROW OF  
**WALL LOGS** INTO THE BOTTOM  
LOGS WITH **SCREWS**.

# BRANTEVIK II 40




AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

## BRANTEVIK II 40




SLIDE THE DOOR IN,  
ATTACH THE HANDLE.

BRANTEVIK II 40




DON`T FORGET TO  
**TIGHTEN** THE LOGS AFTER  
EVERY 3-4 ROWS.

# BRANTEVIK II 40



SLIDE THE WINDOW IN,  
ATTACH THE HANDLE.

BRANTEVIK II 40








INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

BRANTEVIK II 40



6x140 × 4  
Ø 5 mm



INSTALL THE ROOF PURLINS AND ATTACH THEM WITH SCREWS.

BRANTEVIK II 40



6x140 × 6  
Ø 5 mm



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE  
END OF THE **PURLINS** AND ATTACH  
WITH 6 SCREWS, 3 INTO **EACH** NEXT,  
SAW THE LAST **BOARD** TO MAKE IT FIT.



4x50  × 288

BRANTEVIK II 40



FOR THE FASCIA TRIMS INSERT  
SCREWS AFTER EVERY 0,5 METERS.

4x40  
× 44



EAVES EDGES GO ON TOP OF THE ROOFING\*.

\*(NOT INCLUDED)



BRANTEVIK II 40

4x40 × 32

Ø 3 mm

RF



EE



ATTACH ROMBS WITH SCREWS.



BRANTEVIK II 40

4x40 × 4  
Ø 3 mm





14 SCREWS INTO THE FIRST FLOORBOARD,  
7 INTO EACH NEXT, SAW THE  
LAST BOARD TO MAKE IT FIT.

4x50  
× 238



SAW THE **BASEBOARDS**  
AND ATTACH WITH NAILS  
AT **EVERY 0,5** METERS.

1,4x40  
× 30








DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x70 × 12

Ø 8 mm





WINDBOARD




IF DOOR IS TILTED,  
PUSH THE DOOR FRAME SO  
THAT ALL CORNERS ARE  $90^\circ$ .

# BRANTEVIK II 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS OR THERE IS A GAP **BETWEEN** THEM, **ADJUST** 3 SCREWS ON DOOR HINGES.

# BRANTEVIK II 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

# BRANTEVIK II 40

