




PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

DIANA 40



4x40 × 130

4x50 × 900


5x70 × 10

6x140 × 60



M8x70 × 12

1,4x40 × 45

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



DIANA 40




MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 2%

ATTACH FOUNDATION BEAMS
WITH SCREWS.





DIANA 40



6x140 × 16
Ø 5 mm



LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.

DIANA 40




5×70  $\times 4$ 6×140  $\times 14$
 $\varnothing 4 \text{ mm}$  $\varnothing 5 \text{ mm}$ 



THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **4%**


ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.

DIANA 40





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

DIANA 40




SLIDE THE DOOR AND WINDOW IN,
ATTACH THE HANDLES.

DIANA 40




DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

DIANA 40



SLIDE THE **WINDOWS** IN,
ATTACH THE **HANDLES**.



DIANA 40



INSTALL THE DOOR, INSERT CM1 BETWEEN THE WINDOWS AND THE DOOR, ATTACH THEM TO CM1 WITH SCREWS.



DIANA 40

4x40
× 16



ATTACH **LATHS** (LTH1) INTO
WINDOWS AND INTO **CM1**
WITH SCREWS.

4x40
× 18





DIANA 40

INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

6x140 × 4

Ø 5 mm




DIANA 40



INSTALL THE **ROOF** PURLINS AND **ATTACH** THEM WITH SCREWS.

6x140 × 10

Ø 5 mm





DIANA 40



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE **END** OF THE PURLINS AND ATTACH WITH 8 SCREWS, 4 **INTO** EACH NEXT. SAW THE LAST **BOARD** TO MAKE IT FIT.

DIANA 40



4x50  × 448



FOR THE FASCIA TRIMS
INSERT **SCREWS** AFTER EVERY
0,5 METERS.

DIANA 40



4x40
× 52



EAVES EDGES GO ON TOP OF THE ROOFING*.
*(NOT INCLUDED)

DIANA 40

4x40 × 20
Ø 3 mm





ATTACH ROMBS WITH SCREWS.

DIANA 40


4x40
× 4
Ø 3 mm

ROMB





16 SCREWS INTO THE FIRST FLOORBOARD,
8 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.

4x50
× 416




DIANA 40




SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.

1,4×40
× 45



DIANA 40




BB


DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x70 × 12


Ø 8 mm



DIANA 40





WINDBOARD




IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90°.

DIANA 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

DIANA 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

DIANA 40

