















PREPARE THE GROUND, UNWRAP THE PACKAGE,  
LAY OUT THE COMPONENTS, FIND THE TOOLS.

# FREDRIKSTAD 40







LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.





MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 2%

LAY OUT THE **BOTTOM** LOGS,  
**ATTACH** TO THE FOUNDATION.

# FREDRIKSTAD 40




$5 \times 70$    $\times 7$      $6 \times 140$    $\times 21$   
 $\varnothing 4$  mm      $\varnothing 5$  mm 



THE WALL **LOGS** WILL HANG OVER  
THE FOUNDATION **BEAMS** BY  
**APPROXIMATELY** 5MM. THIS OVERHANG  
IS DESIGNED AS A RAIN DRIP. **5%**


ATTACH THE FIRST ROW OF  
**WALL LOGS** INTO THE BOTTOM  
LOGS WITH **SCREWS**.

# FREDRIKSTAD 40





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

FREDRIKSTAD 40




SLIDE THE DOOR IN,  
ATTACH THE HANDLE.

# FREDRIKSTAD 40



DON`T FORGET TO  
**TIGHTEN** THE LOGS AFTER  
EVERY 3-4 ROWS.

FREDRIKSTAD 40





INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

# FREDRIKSTAD 40

6x140 × 9

Ø 5 mm







INSTALL THE ROOF PURLINS AND ROOF ELEMENTS, ATTACH THEM WITH SCREWS.

6x140 × 29

Ø 4 mm



FREDRIKSTAD 40




SCREW RS1 AND RS2 TO  
PURLINS AND ROOF ELEMENTS.

FREDRIKSTAD 40

6x140  
× 36



Ø 5 mm



USE SCREWS TO CONNECT  
ROOF SIDES.




# FREDRIKSTAD 40

4x50 × 12  
Ø 4 mm



SAW ROOFBOARDS SO THAT IT IS POSSIBLE TO ATTACH THEM AGAINST ROOF SIDES.

# FREDRIKSTAD 40





AT THE BACK OF THE HOUSE WILL BE A GAP BETWEEN THE ROOFSIDE AND THE ROOFBOARD 79%

PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE **END** OF THE PURLINS AND ATTACH WITH 10 SCREWS, 5 **INTO** EACH NEXT.


FREDRIKSTAD 40

4x50  
× 240





10 SCREWS INTO THE FIRST FLOORBOARD,  
5 INTO EACH NEXT, SAW THE  
LAST BOARD TO MAKE IT FIT.

4x50  
× 301




FREDRIKSTAD 40



FB

SAW THE **BASEBOARDS**  
AND ATTACH WITH NAILS  
AT **EVERY 0,5** METERS


1,4X40  
× 45




DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x70 × 12


Ø 8 mm



FREDRIKSTAD 40





WINDBOARD






IF DOOR IS TILTED,  
PUSH THE DOOR FRAME SO  
THAT ALL CORNERS ARE 90°.

# FREDRIKSTAD 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS  
OR THERE IS A GAP **BETWEEN** THEM,  
**ADJUST** 3 SCREWS ON DOOR HINGES.

# FREDRIKSTAD 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

# FREDRIKSTAD 40

