




PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

STANDARD




4x40



4x50




5x70



6x140





M8x70




1,4x40



LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



STANDARD



MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.



STANDARD

5x70

Ø 4 mm




6x140

Ø 5 mm




THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **5%**

ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

STANDARD




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

STANDARD




DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

STANDARD




SLIDE THE WINDOW IN,
ATTACH THE HANDLE.

STANDARD



INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.



6x140



Ø 5 mm





STANDARD




INSTALL THE ROOF PURLINS AND ATTACH THEM WITH SCREWS.

STANDARD


6x140
Ø 5 mm



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH SCREWS, SAW THE LAST **BOARD** TO MAKE IT FIT.





STANDARD



FOR THE FASCIA TRIMS INSERT
SCREWS AFTER EVERY 0,5 METERS.

STANDARD

4x40






EAVES EDGES GO ON TOP OF THE ROOFING*.

*(NOT INCLUDED)

4x40

Ø 3 mm




STANDARD

ATTACH ROMBS WITH SCREWS.




STANDARD

4x40
Ø 3 mm





STANDARD

4x50





SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.



1,4x40




STANDARD




WINDBOARD CONNECTS BOTTOM LOG WITH THE TOP LOG. SAW THE WINDBOARD INTO THE RIGHT LENGTH. FOR THE TOP BOLT, DRILL 8MM HOLE THROUGH THE WINDBOARD.



STANDARD





WINDBOARD



DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLTS. 97%


IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90° .

STANDARD



IF **DOORS** ARE IN DIFFERENT HEIGHTS OR THERE IS A GAP **BETWEEN** THEM, **ADJUST** 3 SCREWS ON DOOR HINGES.

STANDARD



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

STANDARD

