














PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

JOKKMOKK 40



LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.





MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%



ATTACH FOUNDATION BEAMS WITH SCREWS.

- 5x70 × 2
- 6x140 × 11
- Ø 4 mm
- Ø 5 mm


JOKKMOKK 40



LAY OUT THE BOTTOM LOGS SO,
THAT DOOR **OPENING** WILL BE
1441 MM WIDE






JOKKMOKK 40






ATTACH LOGS TO THE FOUNDATION.

JOKKMOKK 40




THE WALL LOGS WILL HANG OVER THE FOUNDATION BEAMS BY APPROXIMATELY 5MM. THIS OVERHANG IS DESIGNED AS A RAIN DRIP. 6%

ATTACH THE NEXT ROW OF WALL LOGS INTO THE BOTTOM LOGS WITH SCREWS.




AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

JOKKMOKK 40




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

JOKKMOKK 40




SLIDE THE WINDOW IN,
ATTACH THE HANDLE.

JOKKMOKK 40



DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

JOKKMOKK 40




DRILL 20 MM HOLE IN THE MIDDLE OF THE POSTS BOTTOM. ATTACH POST FOOT WITH SCREWS.

JOKKMOKK 40


4x40 × 4

Ø 3 mm

Ø 20 mm



ADJUSTABLE POST FOOT



B LG-3

2 LG-11

16 LOGS IN PLACE




11/28

POST

SCREW IN THE SECOND PART OF THE POSTFOOT. 46%




ATTACH THE **POSTS** TO THE WALL WITH SCREWS. MAKE SURE THAT THEY **ARE** STRAIGHT.

JOKKMOKK 40



SCREW OUT THE SECOND PART OF THE POST FOOT SO THAT IT TIGHTLY TOUCHES THE GROUND.

4x40
× 4




DEPENDING ON THE SURFACE USE SCREWS OR ANCHOR BOLTS TO ATTACH THE POST FOOT TO THE GROUND. 48%

INSTALL CEILING TRIANGLE AND ATTACH WITH SCREWS INTO THE WALLS.


4x50 × 6 5x70 × 5

JOKKMOKK 40



CEILING DETAIL

40x120




CEILING TRIANGLE

LEAVE 4CM GAP BETWEEN DOOR AND CEILING DETAIL, ATTACH IT INTO WALLS AND INTO CEILING TRIANGLE USING SCREWS 49%


INSTALL THE **GABLE** WITH LONG SCREWS TO THE WALL LOGS ON THE **FRONT** AND **REAR** WALLS.

6x140 × 2

Ø 5 mm



JOKKMOKK 40





ATTACH TOP LOGS INTO WALL LOGS WITH SCREWS.

JOKKMOKK 40

6x140 × 44

Ø 5 mm





INSTALL THE **ROOF** PURLINS AND ATTACH THEM WITH SCREWS.

JOKKMOKK 40

6x140 × 1
5x70 × 8
Ø 5 mm
Ø 4 mm

RFR 1



RFR



INSTALL THE **ROOF** PURLINS AND ATTACH THEM WITH SCREWS.

6x140 × 4
Ø 5 mm

JOKKMOKK 40






INSTALL THE **ROOF** PURLINS (RFB) AND ATTACH THEM WITH SCREWS.

JOKKMOKK 40

5x70 × 18 6x140 × 16

Ø 4 mm

Ø 5 mm



5x70




6x140

66%

INSTALL THE **ROOF** COLLAR BEAMS AND **ATTACH** THEM WITH SCREWS.

JOKKMOKK 40

4x50 × 8
Ø 3 mm





PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE **END** OF THE PURLINS AND ATTACH WITH SCREWS

4x50
× 410





JOKKMOKK 40



ATTACH FASCIA TRIMS
INTO ROOFPURLINS.

JOKKMOKK 40




4x40
× 52



SCREW THE FLOORBOARDS INTO FOUNDATION, SAW THE LAST BOARD TO MAKE IT FIT.

4x50 × 218



JOKKMOKK 40



SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.

1,4X40
× 30




JOKKMOKK 40



DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x70 × 18




Ø 8 mm



WINDBOARD



IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90°.

JOKKMOKK 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

JOKKMOKK 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

JOKKMOKK 40

